

**PAVLÍNEK**<sup>®</sup>  
VÁZACÍ PROSTŘEDKY

EMAIL: [OBCHOD@PAVLINEK.CZ](mailto:OBCHOD@PAVLINEK.CZ)  
TEL: +420 595 693 911  
ŠALOUNOVA 746/31, OSTRAVA VÍTKOVICE  
IČ: 25358511 DIČ: CZ25358511



**DELTA**<sup>®</sup>



## Trolley

DR.0.026 | DR.0.027 | DR.0.036 | DR.0.037

DY.0.036 | DY.0.037

DB.0.036

Instruction manual


**A****B**

**PAVLÍNEK**<sup>®</sup>  
VÁZACÍ PROSTŘEDKY


EMAIL: [OBCHOD@PAVLINEK.CZ](mailto:OBCHOD@PAVLINEK.CZ)  
TEL: +420 595 693 911  
ŠALOUNOVA 746/31, OSTRAVA VÍTKOVICE  
IČ: 25358511 DIČ: CZ25358511



C









D



**PAVLÍNEK**<sup>®</sup>  
VÁZACÍ PROSTŘEDKY

EMAIL: [OBCHOD@PAVLINEK.CZ](mailto:OBCHOD@PAVLINEK.CZ)  
TEL: +420 595 693 911  
ŠALOUNOVA 746/31, OSTRAVA VÍTKOVICE  
IČ: 25358511 DIČ: CZ25358511





**PAVLÍNEK**<sup>®</sup>  
VÁZACÍ PROSTŘEDKY

EMAIL: [OBCHOD@PAVLINEK.CZ](mailto:OBCHOD@PAVLINEK.CZ)  
TEL: +420 595 693 911  
ŠALOUNOVA 746/31, OSTRAVA VÍTKOVICE  
IČ: 25358511 DIČ: CZ25358511



# Trolley

## Instruction manual

### Original instructions

This manual has been translated into multiple languages. The original manual is written in UK English. All other language versions are translations of the original manual.

### Copyright

The content of this manual is protected by copyright and other intellectual property laws. The content of this manual may only be copied, modified, reproduced, translated with express written permission from the manufacturer. This manual may only be published, transmitted, displayed or made available to a third party with express written permission from the manufacturer.

### Disclaimer of liability

The manufacturer cannot be held responsible for personal injury, damage to the machine, or property damage caused by incorrect use, foreseeable misuse, or failure to follow the instructions in this manual. This also applies to unauthorised modifications of the machine and the use of non-approved spare parts, tools, or accessories.

### Contact details

For questions about the machine or this manual, please contact:

#### DELTA Hoisting Equipment

Uiterdijk 6  
1505 GW Zaandam  
The Netherlands  
Tel. +31 20 626 6666  
E-mail: sales@deltahoist.com  
Website: www.deltahoist.com

## 1. Introduction

### 1.1. About this document

This manual contains all instructions and safety information for installation, commissioning, operation, and maintenance of the machine.

This manual is intended for the following individuals:

- Personnel involved in the installation of the machine.
- Personnel involved in the operation of the machine.
- Personnel and qualified technicians involved in the maintenance of the machine.

Ensure you have fully read and understood the instructions in this manual before you transport, install, operate, or maintain the machine. Keep this manual near the machine for future reference. Illustrations are for the general understanding and may differ from the actual machine.

### 1.2. Symbols in this manual

#### 6 WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

#### 6 CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

#### NOTICE

Is used to address practices not related to physical injury.

## 2. Safety

### 2.1. Intended use and reasonably foreseeable misuse

The machine is primarily intended to be used in combination with a hoist. Together, the hoist provides the vertical lifting movement, while the trolley ensures safe horizontal travel along the beam. The primary purpose of the machine is to facilitate material handling operations in various industrial and commercial settings.

The following is considered foreseeable misuse:

- Operating the machine in a manner that deviates from or exceeds the specified operating conditions.
- Failing to comply with the instructions provided in this manual.
- Failing to account for the combined weight of both the hoist and the load when calculating whether the trolley capacity is exceeded.
- Neglecting to rectify faults, malfunctions, or defects of the machine that pose safety risks.
- Neglecting protection from any kind of moisture or water.
- Unauthorised removal or modification of machine parts.
- Using spare parts or accessories that have not been approved by the manufacturer.

### 2.2. Qualification of personnel

This machine may only be operated by personnel who:

- are 18 years of age or older;
- are in good physical and mental condition;
- are competent and qualified;
- have read and understood the instructions in this manual;
- will work in accordance with the instructions provided in this manual;
- have experience operating similar equipment;
- are aware of all potential hazards and act accordingly.

### 2.3. Personal protective equipment (PPE)

To prevent personal injury, the following personal protective equipment must be worn during the






**PAVLÍNEK**<sup>®</sup>  
VÁZACÍ PROSTŘEDKY

EMAIL: [OBCHOD@PAVLINEK.CZ](mailto:OBCHOD@PAVLINEK.CZ)  
TEL: +420 595 693 911  
ŠALOUNOVA 746/31, OSTRAVA VÍTKOVICE  
IČ: 25358511 DIČ: CZ25358511



transportation, installation, operation, and maintenance of the machine:

Symbol	Description
	Wear head protection.
	Wear protective gloves.
	Wear foot protection.

## 2.4. Safety precautions

Despite the safe design and construction of the machine and the prescribed protective measures, residual risks still exist. The following safety precautions must be taken to reduce the residual risk to the minimum:

### 6 WARNING

Falling hazard: Never use the machine to lift, support or transport people.

Crushing hazard:

- Always ensure that the total weight of the hoist and the load does not exceed the rated capacity of the trolley. The complete system of beam, trolley, hoist, and load must be taken into account when calculating safe working load.
- Never exceed the rated capacity of the machine specified on the nameplate.
- Always ensure that the supporting structure and load attaching equipment are rated to support the weight of the machine and the load and are in good condition.
- Always ensure that the end stops are placed on the beam.
- Never lift guided loads without additional protective devices.
- Always ensure all fasteners are properly tightened after completing the installation.
- Never walk or stand under suspended load. Always stand clear of suspended load.
- Never knot or shorten the chain.
- Never operate the machine with a damaged or cracked chain.
- Never weld the chain.
- Never operate a damaged or malfunctioning machine.
- Approval must be obtained from the manufacturer before using the machine in combination with other machines.
- Always inform people when the lifting procedure is about to start.
- Never stand between fixed objects and the suspended load.
- Never place body parts or any objects between the machine and the load.
- Always ensure that the load is resting on solid ground and not under tension when you release

the load.

- Never leave suspended load lifted unattended. Always lower the load onto a flat surface before leaving in unattended.
- Always perform a functional test after any maintenance activity.

Chemical burn hazard: Never lift or transport loads which could cause widespread damage when being dropped.

Distraction hazard:

- Always maintain focus during operation and do not let distractions in your surroundings divert your attention.
- Never operate the machine under the influence of drugs, alcohol, or medication.

Swinging hazard:

Never perform any operations onto the load when the load is lifted.

### 6 CAUTION

Mechanical hazard: Maintenance and repairs must only be performed by qualified personnel.

Safety hazard:

- Always wear the necessary personal protective equipment.
- Never remove the nameplate, operating, and warning labels from the machine.

Tripping hazard: Never leave the machine haphazardly on the ground.

Risk of improper functioning of the machine:

- Always ensure the trolley wheels and beam are clean and free of debris when operating the machine to minimise resistance.
- Never install the trolley on a beam with a  $\leq 1:500$  slope.
- Never use spare parts or accessories that have not been approved by the manufacturer.

Risk of damaging the machine:

- Never drop the machine and avoid bumping.
- Never lift load at an angle. Lifting load at an angle will damage the chain.

## 2.5. Emergency situations

In case of an emergency, do the following:

- Notify others in the vicinity about the emergency.
  - Instruct people to move to a safe distance.
  - Set up safety perimeter around the machine and directly underneath the load to prevent access by unauthorised people.
  - Contact the appropriate emergency services and provide them with all relevant information.
- Follow any additional emergency procedures or protocols specified by your company or site.



### 3. Description of the machine

#### 3.1. Design and function

The machine is designed for use in combination with hoist to transport suspended loads horizontally along a beam. The machine operates manually, either by pushing the load (DR.0.026, DR.0.036, DY.0.036, DB.0.036) or by pulling the hand chain (DR.0.027, DR.0.037, DY.0.037), allowing controlled and guided movement across the beam length. The movement mechanism involves wheels that roll along the lower flange of an I-beam.

The machine is fitted with side plates and adjustable spacers that allow compatibility with a range of beam widths. End stops must be installed on the beam to limit travel and prevent unintentional dismounting.

#### 3.2. Main parts

##### 3.2.1. 0.5 – 5 ton push trolley

See image A

This chapter is only applicable for DR.0.026 / DY.0.036 / DB.0.036.

Part	Quantity
<b>1</b> Two gear case assembly	1x
<b>2</b> Driven wheel	4x
<b>3</b> Bearing	4x
<b>4</b> Axle ring	4x
<b>5</b> Bearing ring	4x
<b>6</b> Hole ring	4x
<b>7</b> Equalizer pin	1x

##### 3.2.2. 0.5 – 5 ton geared trolley

See image B

This chapter is only applicable for DR.0.027 / DY.0.037 / DB.0.037.

Part	Quantity
<b>1</b> Two gear case assembly	1x
<b>2</b> Driven wheel	2x
<b>3</b> Bearing	4x
<b>4</b> Axle ring	4x
<b>5</b> Bearing ring	4x
<b>6</b> Hole ring	4x
<b>7</b> Equalizer pin	1x
<b>8</b> Tooth gear	2x
<b>9</b> Driven spindle	1x
<b>q</b> Right side gear case assembly	1x
<b>w</b> Copper sleeve	1x
<b>e</b> Catch pin	1x
<b>r</b> Chain wheel	1x
<b>t</b> Spacer washer	1x
<b>y</b> Hex castle nut	1x
<b>u</b> Split pin	1x
<b>i</b> Chain	1x

<b>o</b> Roll spindle	1x
<b>p</b> Roll sleeve	1x
<b>a</b> Spacer washer	2x
<b>s</b> Spring washer	1x
<b>d</b> Hex nut	1x

##### 3.2.3. 10 ton push trolley

See image C

This chapter is only applicable for DR.0.03610.

Part	Quantity
<b>1</b> Left side plate	1x
<b>2</b> Right side plate	1x
<b>3</b> Driven shaft	1x
<b>4</b> Driven wheel	2x
<b>5</b> Bearing	4x
<b>6</b> Snap ring	4x
<b>7</b> Bearing cap	4x
<b>3</b> Circlips for hole	4x
<b>9</b> Active wheel	2x
<b>q</b> Hand chain wheel	1x
<b>w</b> Flat washer	1x
<b>e</b> Spring washer	1x
<b>r</b> Slotted nut	3x
<b>t</b> Split pin	4x
<b>y</b> Hand chain	1x
<b>u</b> Sleeve	2x
<b>i</b> Adjust washer	1x
<b>o</b> Roller sleeve	1x
<b>p</b> Axle	1x
<b>a</b> Suspension plate	1x
<b>s</b> Step washer	1x
<b>d</b> Fix pin	2x

##### 3.2.4. 10 – 30 ton geared trolley

See image D

This chapter is only applicable for DR.0.03710 / DR.0.03720 / DR.0.03730.

Part	Quantity
<b>1</b> Hand chain	1x
<b>2</b> Split pin 3.2x22	1x
<b>3</b> Slotted nut M12	1x
<b>4</b> Hand chain wheel	1x
<b>5</b> Box cover assembly component	1x
<b>6</b> Hexagon head bolt M10x50	4x
<b>7</b> Spring washer	4x
<b>8</b> Cylindrical pin 10x50	2x
<b>9</b> Right side plate	1x
<b>q</b> Suspension plate	1x
<b>w</b> Snap ring	2x



<b>e</b>	Bearing	4×
<b>r</b>	Retaining ring	2×
<b>t</b>	Driven wheel	2×
<b>y</b>	Left side plate	1×
<b>u</b>	Split pin	2×
<b>i</b>	Fix pin	2×
<b>o</b>	Axle	2×
<b>p</b>	Roller sleeve	2×
<b>a</b>	Cylindrical pin 8×40	1×
<b>s</b>	Driven shaft assembly component	1×
<b>d</b>	Gear	1×
<b>f</b>	Active shaft assembly component	1×

Capacity (Ton)	Beam width (mm)
0.5	50 – 305
1	58 – 305
2	66 – 305
3	74 – 305
5	90 – 305
10	130 – 305
20	136 – 305
30	136 – 305

## 4. Transport and storage

### 4.1. Transport

- Place the machine in the original packaging or container to protect the machine from damage during transport. Use suitable padding materials to prevent any impact or vibration.
- Properly secure the machine within the transporting vehicle to prevent any movement while during transport.

### 4.2. Storage

Store the machine indoors in a clean and dry environment, on a flat and stable surface. Ensure the storage location has an ambient temperature within the specified range.

Store the machine without any load attached.

## 5. Installation

### 5.1. Checking the contents

- Remove the packaging and padding materials from the machine.
- Check if all parts are present and in good condition.

Quantity	Part
1×	Trolley

### 5.2. Mounting the machine

Check whether the beam meets the following requirements before installing the machine:

- The beam must be designed, tested, and marked with safe working load adequate for the total weight of the trolley, hoist and load to be suspended upon it.
- Found suitable for the desired application.
- Fitted with end stoppers.
- Levelled so that the trolley does not run away by gravity.

Check the beam width is within the parameter of your trolley capacity:

#### 5.2.1. For 0.5 – 5 ton models

See *image E and F*.

- Measure the width of the beam where the machine will be installed.
- Install the equalizer axle to the side plates and turn it clockwise or counter clockwise to adjust the width of the trolley.
  - CAUTION** Risk of damaging the machine: Axle threads needs to be placed correctly to the side plates. When turning the axle it should go smooth, if not, this means that is not placed correctly, immediately stop turning and install again, otherwise threads will get damaged.
  - Double check the beam width in relation to the trolley.
  - Lift the trolley to the beam.
- NOTICE** Keep 3 mm clearance between wheel edge and the beam flange.
- See chapter 5.2.4. for instructions on positioning the trolley wheels based on the beam flange type.
- Install the trolley onto the beam. See *image E*.
  - CAUTION** Risk of improper functioning of the machine. Never install the trolley on a beam with a  $\leq 1:500$  slope.
  - Loosen the hex nut of the roll spindle. See *image F*.
  - Adjust the roll spindle placement to come in contact with the beam.
  - Tighten the hex nut of the roll spindle.

#### 5.2.2. For the 10 ton push trolley model

This chapter is only applicable for DR.0.03610.

See *image F and G*.

- Loosen the two hexagon socket head screws to release the axle of the trolley.
- Remove the left and right side plates and washers from the shaft.
- Measure the width of the beam where the machine will be installed.
- Decide the number of washers to place on both sides of the trolley to ensure the suspension plate is in the middle.
- Place the washers on the axle. Ensure that the amount of washers are the same on each axle and are equally divided.

#### **NOTICE**

- Keep 3 mm clearance between wheel edge and the beam flange.



- The distance between the balance middle part and the bottom of the beam must be 1 mm.
  - Ensure that the contact surface (beam to wheel) is clean of debris.
6. Slide the washers and the left and right side plates back onto the axle.
  7. Check the beam width in relation to the trolley.
  8. Lift the trolley to the beam.
  9. See chapter §5.2.4. for instructions on positioning the trolley wheels based on the beam flange type.
  10. Install the trolley onto the beam.
  11. Tighten the two nuts on both sides of the axle with a wrench. Insert the split pins to fix the axle. *See image G.*
- 6 CAUTION** Risk of improper functioning of the machine. Never install the trolley on a beam with a  $\leq 1:500$  slope.
12. Loosen the hex nut of the roll spindle. *See image F.*
  13. Adjust the roll spindle placement to come in contact with the beam.
  14. Tighten the hex nut of the roll spindle.

### 5.2.3. For the 10/20/30 ton geared trolley model

This chapter is only applicable for DR.0.03710 / DR.0.03720 / DR.0.03730.

*See image F and H.*

1. Loosen the two hexagon socket head screws to release the axles of the trolley.
2. Remove the left side plate and washers from the axles.
3. Measure the width of the beam where the machine will be installed.
4. Decide the number of washers to place on the axle to ensure the suspension plate is in the middle.
5. Place the washers on the axle.

#### NOTICE

- Keep 3 mm clearance between wheel edge and the beam flange.
  - The distance between the balance middle part and the bottom of the beam must be 1 mm.
  - Ensure that the contact surface (beam to wheel) is clean of debris.
6. Slide the washers and the left side plate back onto the axle.
  7. Check the beam width in relation to the trolley.
  8. Lift the trolley to the beam.
  9. See chapter §5.2.4. for instructions on positioning the trolley wheels based on the beam flange type.

## 7. Maintenance

### 7.1. Maintenance schedule

It is recommended to start a commissioning logbook from the first day of use. Check the logbook template provided at the end of this manual.

Users/owners must comply with local, national, and international safety guidelines, which require the machine to be professionally tested and recertified annually. Additionally, shorter recertification intervals may be necessary depending on the working environment.

10. Install the trolley onto the beam.

11. Tighten the nuts on the axles with a wrench. Insert the split pins to fix the axles. *See image H.*

**6 CAUTION** Risk of improper functioning of the machine. Never install the trolley on a beam with a  $\leq 1:500$  slope.

12. Loosen the hex nut of the roll spindle. *See image F.*

13. Adjust the roll spindle placement to come in contact with the beam.

14. Tighten the hex nut of the roll spindle.

### 5.2.4. Trolley wheel positioning

*See image I*

Image I illustrates the required contact surface

between the trolley wheels and the beam,

corresponding to each beam flange type.

The trolley wheels are suitable for both tapered and parallel flange beams.

### 5.2.5. Functionality test

The functional testing of the machine ensures that the machine operates correctly and safely.

1. Suspend a light load from the machine.

2. Make sure all four wheels make contact with the beam.

3. Replace the light load with the maximum safe load.

4. Follow the instructions in chapter §6. to move the load along the full length of the beam.

## 6. Operation

### 6.1. Preparation

**6 WARNING** Crushing hazard: Never operate a damaged or malfunctioning machine.

- Check if the trolley and additional equipment is correctly installed.
- Make sure that the additional equipment has the same or less capacity as the trolley, it may never exceed the working load limit.
- Check if all bolts and nuts are tightened.

### 6.2. Handling load

1. Secure the load to the hole in the equalizer pin.

To move the load:

- a. For a push trolley: Push the load manually.
- b. For a geared trolley: pull on the chain to move the load along the beam.



**PAVLÍNEK**<sup>®</sup>  
VÁZACÍ PROSTŘEDKY

EMAIL: [OBCHOD@PAVLINEK.CZ](mailto:OBCHOD@PAVLINEK.CZ)  
TEL: +420 595 693 911  
ŠALOUNOVA 746/31, OSTRAVA VÍTKOVICE  
IČ: 25358511 DIČ: CZ25358511



Frequency	Activities	Instructions
Periodically	Check the side plates, shaft, wheels and hand chain for damage and deformation.	
	Check the legibility of the labels.	-
	Check the equipment for loose parts.	-
Annually	Inspection/re-certification lifting gear.	Please follow the according local guidelines for yearly inspection of the machine.

If dysfunctions are detected, please contact a certified professional.

If any abnormal situation occurs during any of the checks, immediately take the machine out of use and contact your dealer or a certified professional.

## 7.2. Other maintenance

Maintenance activities that are not described in this chapter may only be performed by qualified personnel. Please contact your supplier.

## 8. Disposal

### 8.1. Disposal of packaging waste

Dispose the packaging material in accordance with the local regulations.

### 8.2. Disposal of machine parts

If the machine is defective, please contact your supplier. It may still be possible to repair the machine. If you still need to dispose the product, separate, and dispose the components of the machine into the applicable waste streams based on their material, in accordance with the local regulations.

## 9. Technical data

### 9.1. Capacity per model

Push trolley Article code	Capacity Ton
DR.0.02600500 DY.0.03600500 DB.0.03600500	0.5
DR.0.02601000 DY.0.03601000 DB.0.03601000	1
DR.0.02602000 DY.0.03602000 DB.0.03602000	2
DR.0.02603000 DY.0.03603000	3
DR.0.02605000 DY.0.03605000	5

Push trolley Article code	Capacity Ton
DR.0.03610000	10

Push trolley Article code	Capacity Ton
DR.0.02700500 DY.0.03700500	0.5
DR.0.02701000 DY.0.03701000	1
DR.0.02702000 DY.0.03702000	2
DR.0.02703000 DY.0.03703000	3
DR.0.02705000 DY.0.03705000	5

Push trolley Article code	Capacity Ton
DR.0.03710000	10
DR.0.03720000	20
DR.0.03730000	30

### 9.2. Main dimensions

For a complete overview of the main dimensions of the machine and other data, please visit [www.deltahoist.com](http://www.deltahoist.com) for more information.



### 9.3. Rating plate

The rating plate is located on the machine. The following information can be found on the rating plate:

- Company name
- Capacity
- Company website
- Serial number
- Manufacturing year

## 10. Declaration of conformity

Hereby the manufacturer:

DELTA Hoisting Equipment  
Uiterdijk 6, 1505 GW, Zaandam, Netherlands

declares that this product complies with all applicable provisions of the Machinery Directive 2006/42/EC and the electromagnetic compatibility directive 2014/30/EU.

Additionally, this product has been thoroughly inspected and tested. The data is in compliance with the technical requirements, which is gathered in our documentation.

<b>Description:</b>	DELTA – Push trolley	DELTA – Geared trolley
<b>Type:</b>	DR.0.02600500 DY.0.03600500 DB.0.03600500	DR.0.02700500 DY.0.03700500
	DR.0.02601000 DY.0.03601000 DB.0.03601000	DR.0.02701000 DY.0.03701000
	DR.0.02602000 DY.0.03602000 DB.0.03602000	DR.0.02702000 DY.0.03702000
	DR.0.02603000 DY.0.03603000	DR.0.02703000 DY.0.03703000
	DR.0.02605000 DY.0.03605000	DR.0.02705000 DY.0.03705000
	DR.0.03610000	DR.0.03710000
		DR.0.03720000
		DR.0.03730000

Authorized person:

**Name:** M.F. Stam  
**Position:** Director  
**Place:** DELTA Hoisting Equipment, Uiterdijk 6, 1505 GW Zaandam, Netherlands  
**Signature:**



**PAVLÍNEK**<sup>®</sup>  
VÁZACÍ PROSTŘEDKY

EMAIL: [OBCHOD@PAVLINEK.CZ](mailto:OBCHOD@PAVLINEK.CZ)  
 TEL: +420 595 693 911  
 ŠALOUNOVA 746/31, OSTRAVA VÍTKOVICE  
 IČ: 25358511 DIČ: CZ25358511



# Logbook / Commissioning Log

<b>Company name</b>	<b>Article:</b>
	<b>Model:</b>
	<b>Serial number:</b>
	<b>First use*:</b>
	<b>Last inspection:</b>

\* Please make sure that you perform the required / mandatory annual inspection based on this date.

## Before use / Periodically

Type of inspection	Date	Performed by

## Annually

Type of inspection	Date	Performed by

After successful inspection and when put in use again, please start the logbook again from the inspection date. Use last inspection as reference date for the next annual inspection.

Always keep inspection certificates together with the logbook for own administration.

If you have any malfunctions, put the equipment out of use, contact a certified professional.



**PAVLÍNEK**<sup>®</sup>  
VÁZACÍ PROSTŘEDKY

EMAIL: [OBCHOD@PAVLINEK.CZ](mailto:OBCHOD@PAVLINEK.CZ)  
TEL: +420 595 693 911  
ŠALOUNOVA 746/31, OSTRAVA VÍTKOVICE  
IČ: 25358511 DIČ: CZ25358511





**PAVLÍNEK**<sup>®</sup>  
VÁZACÍ PROSTŘEDKY

EMAIL: [OBCHOD@PAVLINEK.CZ](mailto:OBCHOD@PAVLINEK.CZ)  
TEL: +420 595 693 911  
ŠALOUNOVA 746/31, OSTRAVA VÍTKOVICE  
IČ: 25358511 DIČ: CZ25358511



DELTA Hoisting Equipment  
Uiterdijk 6  
1505GW Zaandam  
The Netherlands  
T +31(0)20 626 6666  
E [sales@deltahoist.com](mailto:sales@deltahoist.com)



EN - Original instructions  
V1.0 - October 2025